Turn S2 at rest before starting the Remote.

The potentiomiter is activated with the up or down movement of S1